

VIII.3.3-RES-SNGL-S-PASN26 SUBROUTINE PASN26

Description

Subroutine PASN26 sets the discharge at the end of a time interval equal to the inflow. However if inflow is less than required minimum outflow then the discharge will be later set to required minimum outflow.

Calling Sequence

CALL PASN26 (STOR,ELEV)

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
STOR	Input	R*4	NSE	Storages for pool elevation versus storage relation
ELEV	Input	R*4	NSE	Elevations for elevation versus storage relation

Dimension variable is in common block RESV26.